



Teldat Router

E1/PRI ISDN Interface

Doc. DM529-I Rev. 8.30

May, 2000

INDEX

Chapter 1 Introduction.....	3
1. Introduction to E1/PRI ISDN interface	4
Chapter 2 Configuration	5
1. E1/PRI ISDN Interface Configuration	6
1.1. TYPE OF INTERFACE	6
a) <i>Interface configured as E1</i>	6
b) <i>Interface configured as Primary ISDN</i>	6
1.2. CRC-4.....	6
1.3. MAXIMUM FRAME SIZE	7
1.4. MODE	7
2. E1/PRI ISDN Configuration Commands	8
2.1. ? (HELP)	9
2.2. DISABLE.....	9
2.3. ENABLE.....	9
2.4. LIST.....	10
2.5. SET.....	10
a) <i>SET CIRCUIT</i>	10
• SET CIRCUIT MAX-FRAME-LENGTH.....	11
• SET CIRCUIT TYPE.....	11
b) <i>SET GLOBAL</i>	12
• SET GLOBAL INTERFACE-TYPE.....	12
• SET GLOBAL LOCAL-ADDRESS	12
• SET GLOBAL MAX-FRAME-LENGTH.....	13
• SET GLOBAL MODE	13
2.6. EXIT	13
Chapter 3 Monitoring.....	14
1. E1/PRI ISDN interface monitoring.....	15
1.1. ? (HELP).....	16
1.2. CALLS.....	16
a) <i>CALLS ACTIVE</i>	16
b) <i>CALLS CLEARED</i>	17
1.3. CAUSE	17
1.4. CLEAR	18
a) <i>CLEAR CALLS</i>	18
b) <i>CLEAR STATISTICS</i>	18
1.5. STATE.....	18
1.6. STATISTICS	19
1.7. EXIT	19
2. E1/PRI ISDN interface statistics.....	21

Chapter 1

Introduction



Chapter 2 Configuration



1. E1/PRI ISDN Interface Configuration

This chapter describes the parameters which can be configured in the E1/PRI ISDN interface. Depending on the behavior you require from the router, you will need to correctly configure the distinct options.

1.1. TYPE OF INTERFACE

The first thing to consider is the type of interface you are going to configure as it depends on this whether certain parameters are applicable or not.

a) Interface configured as E1

In the case of an E1 interface, all the channels (except 0) are available to the user as 64 Kbps B channels and can be used as required.

Regarding the type of connection that can be established for the E1 interface channels, only permanent connections are possible as all the circuits are configured as *PVCs*.

Given that all the circuits are permanent, it doesn't make any sense to assign a number to the interface to receive calls (there are no calls) consequently, you cannot configure a 'local address'.

b) Interface configured as Primary ISDN

If, on the other hand, you wish to use the interface as Primary ISDN, channel 16 is not available as this is used for signaling (channel D). The rest of the available channels can be used as required (except 0).

In this case, you can configure the channels as permanent (*PVC*) or switched (*SVC*).

It is also possible to configure a number or a local address to which ISDN calls can be carried out.

The PVC channels are always assigned so other users cannot use them. The SVCs however are assigned at the moment the call is produced in order to establish the data link and therefore are shared among all the possible users (the channel through which the communication is going to be established is unknown a priori).

1.2. CRC-4

When it is necessary to provide additional protection for frame alignment simulation and/or when you wish to count on a better error monitoring capacity, you can use the *CRC-4, cyclic redundancy check-4 method*. This procedure is extensively described in the G.704 recommendation. Generally this process uses the channel 0 bits series (frame bits numbered from 1 to 8) in order to determine if this functionality is active and to carry out an encoding/decoding to check that the frame arrives aligned etc.

The router can be configured to operate whether the CRC-4 procedure is applied or not.

NOTE: When configuring the router, you must bear in mind the possibility of interoperation with other devices which do not permit CRC-4. This means you must enable or disable according to the devices operating together.



1.3. MAXIMUM FRAME SIZE

This permits you to establish a maximum frame size through the interface. The maximum size can be configured afterwards so that each channel cannot exceed the 'general' maximum size.

1.4. MODE

The mode option refers to the clock signals. In the terminal devices, the network supplier provides the clock signal received by the router. However on some occasions it may be necessary that one of the devices provides the clock signals. Under these circumstances you must advise the indicated router to provide these signals.



2. E1/PRI ISDN Configuration Commands

The E1/PRI ISDN configuration commands are described in this section. Through these commands you can configure the router behavior over this interface in order to achieve the functional specifications required.

The commands available here can be seen in the below table:

Command	Function
? (HELP)	Permits you to view the available commands or their options.
DISABLE	Disables the CRC-4.
ENABLE	Enables the CRC-4.
LIST	Displays the interface configuration information.
SET	Permits you to configure the value for various interface parameters according to the required option.
EXIT	Returns to the configuration <i>Config></i> prompt.

The letters written in **bold**, are the minimum number of characters required to activate the command.

Accessing the E1/PRI ISDN Configuration environment

The configuration commands must be entered at the E1/PRI ISDN interface configuration prompt (E1/PRI config>). In order to access this prompt:

1. At the configuration prompt (Config>), the list of interfaces and associated interface number is displayed through the **LIST DEVICES** command.
2. Enter the command **NETWORK** followed by the interface number associated to the **E1/PRI ISDN** interface.

Example:

```
Config>LIST DEVICES
Con   Ifc Type of interface          CSR   CSR2  int
---   --  -
---   2  PPP Generic Dial              0     0     0
---   3  PPP Generic Dial              0     0     0
---   4  Router->Node                 0     0     0
---   5  Node->Router                 0     0     0
ISDN 1  1  G.703 port (E1)             F001600 F000C00 9E
LAN   0  Ethernet                   A000000          1D
WAN1  6  X25                         F001620 F000D00 9D
Config>NETWORK 1
-- E1 / Primary ISDN Configuration --
E1/PRI config>
```



2.1. ? (HELP)

Use the ? command (HELP) in order to list the valid commands at the layer where the router is programmed. You can also use this command after a specific command in order to list the available options.

Syntax:

```
E1/PRI config>?
```

Example:

```
E1/PRI config>?  
DISABLE  
ENABLE  
SET  
LIST  
EXIT  
E1/PRI config>
```

2.2. DISABLE

The **DISABLE** command disables the use of the CRC-4, cyclic redundancy check-4 method in the interface.

Syntax:

```
E1/PRI config>DISABLE CRC-4
```

Example:

```
E1/PRI config>DISABLE CRC-4  
E1/PRI config>
```

2.3. ENABLE

The **ENABLE** command enables the use of the CRC-4, cyclic redundancy check-4 method in the interface.

Syntax:

```
E1/PRI config>ENABLE CRC-4
```

Example:

```
E1/PRI config>ENABLE CRC-4  
E1/PRI config>
```

NOTE: *In cases where you wish to enable this parameter, you must make sure that the devices, which are going to interact, are capable of supporting CRC-4.*



2.4. LIST

The **LIST** command permits you to display the interface configuration, including the general parameters and those for each independent channel.

Syntax:

```
E1/PRI config>LIST
```

Example:

```
E1/PRI config>LIST
CRC-4                : Enabled
Local address        :
Maximum frame length : 2048
Interface type       : PRI ISDN
Mode                 : EQUIPMENT

      B-01 B-02 B-03 B-04 B-05 B-06 B-07 B-08 B-09 B-10
-----
MTU    2048 2048 2048 2048 2048 2048 2048 2048 2048 2048
Type   svc  svc  svc  svc  svc  svc  svc  svc  svc  svc

      B-11 B-12 B-13 B-14 B-15 B-17 B-18 B-19 B-20 B-21
-----
MTU    2048 2048 2048 2048 2048 2048 2048 2048 2048 2048
Type   svc  svc  svc  svc  svc  svc  svc  svc  svc  svc

      B-22 B-23 B-24 B-25 B-26 B-27 B-28 B-29 B-30 B-31
-----
MTU    2048 2048 2048 2048 2048 2048 2048 2048 2048 2048
Type   svc  svc  svc  svc  svc  svc  svc  svc  svc  svc

E1/PRI config>
```

2.5. SET

The **SET** command permits you to configure various parameters both global (the whole interface) and parts of a determined circuit.

Syntax:

```
E1/PRI config>SET <option, parameter, value>
```

NOTE: *If you do not enter all the necessary parameters in the command line, the device will request these.*

```
E1/PRI config>SET ?
CIRCUIT
GLOBAL
```

a) SET CIRCUIT

Permits you to establish each circuit's own parameters.



Syntax:

```
E1/PRI config>SET CIRCUIT ?  
MAX-FRAME-LENGTH  
TYPE
```

- **SET CIRCUIT MAX-FRAME-LENGTH**

Through this parameter, you can configure the maximum frame length through the specified channel. The permitted values are 1024, 2048 and 4096 bytes. The default value is 2048 bytes.

Syntax:

```
E1/PRI config>SET CIRCUIT MAX-FRAME-LENGTH <circuit_number, maximum_frame_size
```

Example:

```
E1/PRI config>SET CIRCUIT MAX-FRAME-LENGTH  
Enter circuit (1-31)[1]?2  
Maximum frame length (1024,2048,4096)[2048]?4096  
E1/PRI config>
```

NOTE: *The maximum frame length associated to a circuit cannot exceed that configured for the interface.*

- **SET CIRCUIT TYPE**

This configures the type of connection to be established over the circuits (channels).

Syntax:

```
E1/PRI config>SET CIRCUIT TYPE <circuit_type, circuit_number>
```

This can be **PERMANENT** or **SWITCHED**.

```
E1/PRI config>SET CIRCUIT TYPE ?  
PERMANENT  
SWITCHED
```

Example:

```
E1/PRI config>SET CIRCUIT TYPE SWITCHED  
Enter circuit (1-31)[1]?  
E1/PRI config>
```

or

```
E1/PRI config>SET CIRCUIT TYPE PERMANENT  
Enter circuit (1-31)[1]?  
E1/PRI config>
```

NOTE: *When you configure the interface as E1, you cannot configure the type of circuit as these are permanent.*



b) SET GLOBAL

Configures the interface global parameters.

Syntax:

```
E1/PRI config>SET GLOBAL ?  
MAX-FRAME-LENGTH  
LOCAL-ADDRESS  
INTERFACE-TYPE  
MODE
```

• SET GLOBAL INTERFACE-TYPE

Establishes the interface behavior: as E1 (**E1**) or as Primary ISDN (**PRI**).

Syntax:

```
E1/PRI config>SET GLOBAL INTERFACE-TYPE <interface_type>
```

```
E1/PRI config>SET GLOBAL INTERFACE-TYPE ?  
E1  
PRI
```

Example:

```
E1/PRI config>SET GLOBAL INTERFACE-TYPE E1  
E1/PRI config>
```

or

```
E1/PRI config>SET GLOBAL INTERFACE-TYPE PRI  
E1/PRI config>
```

• SET GLOBAL LOCAL-ADDRESS

Establishes the local ISDN number associated to the interface in order to receive calls (this parameter is only significant when the interface is a PRI ISDN).

Syntax:

```
E1/PRI config>SET GLOBAL LOCAL-ADDRESS <ISDN_number>
```

Example:

```
E1/PRI config>SET GLOBAL LOCAL-ADDRESS  
Local address []?913141592  
E1/PRI config>
```



- **SET GLOBAL MAX-FRAME-LENGTH**

The maximum frame length through the interface is configured through this parameter. The permitted values are 1024, 2048 and 4096 bytes. The default value is 2048 bytes.

Syntax:

```
E1/PRI config>SET GLOBAL MAX-FRAME-LENGTH <maximum_frame_size>
```

Example:

```
E1/PRI config>SET GLOBAL MAX-FRAME-LENGTH
Maximum frame length (1024,2048,4096)[2048]?
E1/PRI config>
```

- **SET GLOBAL MODE**

This configures the device functionality as **EQUIPMENT** (the router will receive external clock signals and act as a 'terminal') or **LINE** (the router supplies the line clocks and acts as the 'network').

Syntax:

```
E1/PRI config>SET GLOBAL MODE <mode>
```

```
E1/PRI config>SET GLOBAL MODE ?
EQUIPMENT
LINE
```

Example:

```
E1/PRI config>SET GLOBAL MODE EQUIPMENT
E1/PRI config>
```

or

```
E1/PRI config>SET GLOBAL MODE LINE
E1/PRI config>
```

2.6. EXIT

Through this command, you exit the E1/PRI ISDN interface configuration menu and return to the configuration *Config*> prompt.

Syntax:

```
E1/PRI config>EXIT
```

Example:

```
E1/PRI config>EXIT
Config>
```



Chapter 3 Monitoring



1. E1/PRI ISDN interface monitoring

This section summarizes and explains all the E1/PRI ISDN interface monitoring commands. These commands permit you to monitor the interface behavior.

The available monitoring commands are seen in the below table:

Command	Function
? (HELP)	Permits you to list the available commands and their options.
CALLS	Displays the calls produced.
CAUSE	Returns the meanings of the call release codes.
CLEAR	Permits you to initialize the channel statistics and clear the released calls buffer.
STATE	Displays the state and statistics of a B channel physical level.
STATISTICS	Displays the statistics of an active B channel.
EXIT	Returns to the global monitoring prompt (+).

The letters written in **bold**, are the minimum number of characters required to activate the command.

Accessing the E1/PRI ISDN Monitoring environment

The E1/PRI ISDN interface monitoring commands must be entered at the *E1/PRI>* monitoring prompt. In order to access this prompt you need to carry out the following steps:

1. At the monitoring prompt (+), the list of interfaces and associated interface number is displayed through the **DEVICES** command.
2. Enter the command **NETWORK** followed by the interface number associated to the E1/PRI ISDN interface.

Example:

```
+DEVICE
Ifc Interface      CSR      Vect      Auto-test  Auto-test  Maintenance
      Interface      CSR      Vect      valids    failures  failures
0   Eth/0      A000000    1d        1          0          0
1   PRI/0      F001600    9e        1          1          0
2   PPP/0              0         0         1          2          0
3   PPP/1              0         0         1          2          0
4   R->N/0      0         0         1          0          0
+NETWORK 1

-- E1 / Primary ISDN Console --
E1/PRI>
```



1.1. ? (HELP)

Use the ? command (HELP) in order to list the valid commands at the layer where the interface is being monitored. You can also use this command after a specific command in order to list the available options.

Syntax:

```
E1/PRI>?
```

Example:

```
E1/PRI>?  
CLEAR  
CAUSE  
STATISTICS  
STATE  
CALLS  
EXIT  
E1/PRI>
```

1.2. CALLS

Information on the calls is displayed through the **CALLS** command:

ACTIVE: displays data on the active calls

CLEARED: displays information on the released calls.

Syntax:

```
E1/PRI>CALLS <call_type>
```

```
E1/PRI>CALLS ?  
ACTIVE  
CLEARED
```

a) CALLS ACTIVE

Example:

```
E1/PRI>CALLS ACTIVE  
  
TYPE   CALLED NUMBER      CALLING NUMBER REF  CHAN   T/START   D/START   CHARGE  
OUT    384200              001  1-B1   17:11:47  01/20/00  000000  
  
E1/PRI>
```

The meaning of the various fields is as follows:

TYPE Incoming (IN) or outgoing (OUT).

CALLED NUMBER Telephone number called.

CALLING NUMBER Number of telephone calling.

REF Value of call reference in use.



CHAN	This is the line and channel through which the call has been established.
T/START	Indicates the time the call was established.
D/START	Indicates the day the call was established.
CHARGE	Cost of the call (if the network provides this).

b) CALLS CLEARED

Example:

```
E1/PRI>CALLS CLEARED

L T      CALLED N.  CALLING N.  CC  DC  T/START      T/END      D/START      D/END      CHARGE
1 0      384200          016 000 16:48:05 17:10:57 01/20/00 01/20/00 000000

E1/PRI>
```

The meaning of the various fields is as follows:

L T	Line identifier and channel type.
CALLED N.	Telephone number called.
CALLING N.	Number of telephone calling.
CC	Call release code (cause).
DC	Diagnostic code.
T/START	Time the call was established.
T/END	Time the call was released.
D/START	Day the call was established.
D/END	Day the call was released.
CHARGE	Cost of the call (if the network provides this).

NOTE: *In cases of Permanent links, calls are not generated as the links are permanently established.*

1.3. CAUSE

The **CAUSE** command returns the meaning of a specific release code. This command is for informative purposes in order to make it easier to understand the presented data.

Syntax:

```
E1/PRI>CAUSE <cause_code>
```



Example:

```
E1/PRI>CAUSE 3
Cause (3): No route to the destination
E1/PRI>
```

1.4. CLEAR

CLEAR enables you to delete the statistics of a specific channel or all of them such as the released calls buffer.

Syntax:

```
E1/PRI>CLEAR <option>
```

```
E1/PRI>CLEAR ?
STATISTICS
CALLS
```

a) CLEAR CALLS

Clears the released calls buffer.

Example:

```
E1/PRI>CLEAR CALLS
E1/PRI>
```

b) CLEAR STATISTICS

Deletes the B channel statistics. If you specify a channel number it will only delete the statistics relevant to that channel while if you do not indicate a number all the statistics for all the channels are deleted.

Syntax:

```
E1/PRI>CLEAR STATISTICS <[channel]>
```

Example:

```
E1/PRI>CLEAR STATISTICS 5
E1/PRI>
```

1.5. STATE

The **STATE** command displays a B channel's physical layer statistics and state.



Syntax:

```
E1/PRI>STATE <channel>
```

Example:

```
E1/PRI>STATE 15

          Statistics circuit B-15

Lost Rx Frames           0   Non aligned Rx frames           0
Too large frames         0   Aborted Rx sequences           0
CRC error Rx frames      0   Incomplete Rx frames          0
Rx fifo failure          0   Tx fifo failure                0

E1/PRI>
```

The meanings of the fields that appear above are the following:

- Lost Rx Frames** Frames lost at reception.
- Too large frames** Frames received that exceed the MTU maximum length.
- CRC error Rx frames** Frames received with an error in the CRC code.
- Rx fifo failure** Errors due to the reception buffer being unable to store all the frames on reception.
- Non-aligned Rx frames** Received frames non-aligned to octet.
- Aborted Rx sequences** Illegal sequence of ‘1’s found in the frame.
- Incomplete Rx frames** Incomplete frames.
- Tx fifo failure** Errors in the frame transmission as the interface is incapable of taking the frames from the transmission buffer sufficiently fast enough in order to transmit them.

1.6. STATISTICS

The **STATISTICS** command displays the B channels statistics. If you do not indicate a specific channel the device displays a statistics list for all the B channels.

Syntax:

```
E1/PRI>STATISTICS <[channel]>
```

Example:

```
E1/PRI>STATISTICS 1
Circuit   Pkts Rx   Bytes Rx   Pkts Tx   Bytes Tx
B-1       2849      167498    2849      167503
E1/PRI>
```

1.7. EXIT

Through this command you return to the global monitoring prompt (+).



Syntax:

```
E1/PRI>EXIT
```

Example:

```
E1/PRI>EXIT  
+
```



2. E1/PRI ISDN interface statistics

In order to view the interface statistics, enter the **DEVICE** command indicating the number of the interface whose statistics you wish to view at the monitoring prompt (+).

Example:

```
+DEVICE

Ifc Interface      CSR      Vect      Auto-test  Auto-test  Maintenance
      Interface      CSR      Vect      valids    failures  failures
0   Eth/0         A000000  1d        1         0         0
1   PRI/0         F001600  9e        0         0         0
2   PPP/0         0        0         1         2         0
3   PPP/1         0        0         1         2         0
4   R->N/0        0        0         1         0         0
+DEVICE 1

Ifc Interface      CSR      Vect      Auto-test  Auto-test  Maintenance
      Interface      CSR      Vect      valids    failures  failures
1   PRI/0         F001600  9e        0         0         0

-- DS2153Q --
Rx Status: OK
RIR:89  SSR:00  SR1:50  SR2:FB  VCR: 0  FAS: 0

Layer 1 status: F1

+
```

The meaning of the fields is as follows:

- | | |
|-------------------------------------|--|
| Ifc | Interface number. |
| Interface | Type of interface and index. |
| CSR | control/status/data register address. |
| Vect | Interruption vector associated to the interface. |
| Auto-test valids | Number of successful Auto-tests. |
| Auto-test failures | Number of failed Auto-tests. |
| Maintenance failures | Number of maintenance failures. |
| Rx Status | Reception Status. |
| RIR, SSR, SR1, SR2, VCR, FAS | Information on the status of the chip. |
| Layer 1 status | Physical layer status. |

