



# **Teldat Router**

## **XOT Protocol**

*Doc. DM713-I Rev. 10.00*

*February, 2003*

# INDEX

---

<b>Chapter 1 Introduction.....</b>	<b>1</b>
1. Introduction to XOT Protocol.....	2
<b>Chapter 2 Configuration.....</b>	<b>3</b>
1. Configuration Commands.....	4
1.1. ? (HELP).....	4
1.2. ADDRESS.....	4
1.3. DISABLE.....	5
a) <i>DISABLE EXT-PACKET-MODE</i> .....	5
1.4. ENABLE.....	5
a) <i>ENABLE EXT-PACKET-MODE</i> .....	5
1.5. FACILITY.....	5
1.6. LIST.....	7
a) <i>LIST ADDRESS</i> .....	7
b) <i>LIST ALL</i> .....	7
c) <i>LIST FACILITY</i> .....	8
d) <i>LIST PORT</i> .....	8
e) <i>LIST ROUTING</i> .....	9
1.7. NO.....	9
a) <i>NO ADDRESS</i> .....	9
b) <i>NO FACILITY</i> .....	9
c) <i>NO NA-CALLING</i> .....	9
d) <i>NO ROUTING</i> .....	10
1.8. RESTORE.....	10
a) <i>RESTORE ALL</i> .....	10
b) <i>RESTORE PORT</i> .....	10
1.9. ROUTING.....	10
1.10. SET.....	11
a) <i>SET CHANNEL-DIRECTION</i> .....	12
• <i>SET CHANNEL-DIRECTION DECREASING</i> .....	12
• <i>SET CHANNEL-DIRECTION INCREASING</i> .....	12
b) <i>SET NA-CALLING</i> .....	12
c) <i>SET PACKET-SIZE</i> .....	12
d) <i>SET PACKET-WINDOW</i> .....	12
e) <i>SET PROCESS-NA-CALLING</i> .....	12
f) <i>SET SVC</i> .....	13
• <i>SET SVC LOW</i> .....	13
• <i>SET SVC HIGH</i> .....	13
1.11. EXIT.....	13
<b>Chapter 3 Monitoring.....</b>	<b>14</b>
1. Monitoring Commands.....	15
1.1. ? (HELP).....	15
1.2. LIST.....	15
a) <i>LIST STATE</i> .....	15
1.3. EXIT.....	15
<b>Chapter 4 XOT Interfaces.....</b>	<b>17</b>
1. Creating XOT interfaces.....	18
2. Configuring XOT Interfaces.....	19
3. Configuring the X.25 parameters.....	20
3.1. Assigning Addresses.....	21

3.2. Liberation causes and diagnostics ..... 22

# Chapter 1

## Introduction



# 1. Introduction to XOT Protocol

---

## **X.25 over TCP/IP -XOT- (X. 25 sobre TCP/IP)**

The XOT Interface allows X.25 packets to be transported over TCP/IP networks. This demands a reliable link level to transfer the packets. This link is generally LAPB (or LAPD) protocol in packet switch networks. However, when it is a different type of network, e.g. Frame Relay switch networks the LAPB link must be substituted for a distinct reliable link. If the TCP/IP is chosen as a link layer, this permits the interconnection of terminals (which operate in X.25 over Frame Relay networks and local Ethernet, Token Ring networks etc.), as the packet sequences are converted into datagram sequences. These are forwarded and routed over all IP networks until they reach their destination where the X.25 packets are recovered.

This method of encapsulating X.25 over TCP is defined in the RFC (Request For Comments) 1613 standard with which the XOT is compatible.

# Chapter 2

## Configuration



# 1. Configuration Commands

---

The XOT Protocol configuration is accessed through the main menu in the following way:

1. At the (\*) prompt, enter **PROCESS 4** (or **P 4**).
2. At the configuration (Config>) prompt, enter **NODE XOT** or **NETWORK xxxx**, xxxx being the name of the XOT interface that can be viewed through **LIST DEVICES**.
3. At the XOT protocol configuration (XOT Config>) prompt, use the configuration commands described in this chapter to configure the XOT protocol parameters.

In this chapter the XOT Protocol configuration commands are explained in detail.

<b>Command</b>	<b>Function</b>
? (HELP)	Lists all the available commands or options.
ADDRESS	Associates an NA to an IP address.
DISABLE	Disable a functionality.
ENABLE	Enable a functionality
FACILITY	Configures X.25 facilities.
LIST	List the parameters.
NO	Permits you to delete a parameter or an element from a table.
RESTORE	Restore the default values.
ROUTING	Adds routing.
SET	Set the value of a parameter.
EXIT	Return to Config> prompt.

## 1.1. ? (HELP)

Displays a list of the available commands or their options.

**Syntax:**

```
XOT Config>?
```

**Example :**

```
XOT config>?  
ADDRESS  
DISABLE  
ENABLE  
FACILITY  
LIST  
NO  
RESTORE  
ROUTING  
SET  
EXIT  
XOT Config>
```

## 1.2. ADDRESS

Allows you to assign a determined NA to an IP address. The NAs can be generic. You can also set an alternative IP address which you can use to connect when the configured timeout terminates in this command.

### Syntax:

```
XOT config>ADDRESS <na>
ip-address                ip-address to establish a tcp connection
alternative-ip-address    alternative-ip-address to try if primary fails
timeout                   timeout to try with the alternative ip address
```

Each option has the following meaning:

*<na>* Calling NA for the indicated IP address.  
*ip-address* IP address to which an X.25 address is associated. (This parameter must be introduced - mandatory).  
*alternative-ip-address* Alternative-ip-address to try if primary fails  
*timeout* Wait time before trying with the alternative IP address.

### Example:

```
XOT Config>ADDRESS 21324242 IP 192.22.24.56 AL 172.43.55.23 TI 120
XOT Config>
```

## 1.3. DISABLE

### Syntax:

```
XOT Config>DISABLE ?
EXT-PACKET-MODE
XOT Config>
```

#### a) DISABLE EXT-PACKET-MODE

Configures the port to work in 8 mode.

### Example:

```
XOT Config>DISABLE EXT-PACKET-MODE
XOT Config>
```

## 1.4. ENABLE

### Syntax:

```
XOT Config>ENABLE ?
EXT-PACKET-MODE
XOT Config>
```

#### a) ENABLE EXT-PACKET-MODE

Configures the port to work in 128 mode.

### Example:

```
XOT Config>ENABLE EXT-PACKET-MODE
XOT Config>
```

## 1.5. FACILITY

This permits you to change the called NA, add or change user data, and add or change facilities in the call packets (window and packet length negotiation, reverse charge, closed user group and network



user identifier). In order to eliminate a facility entry, introduce the command **NO** in front of **FACILITY**. For further information, please see the section describing the **NO** command function.

**Syntax:**

XOT config>FACILITY <id>	
called	window and packet length called facilities
window	window value
packet-length	packet-length value
caller	window and packet length caller facilities
window	window value
packet-length	packet-length value
na-value	na value to match (digit or X)
new-na-value	new na value (digit , X or S)
no	
reverse-charge	Disable reverse charge facility option
packet-length-negotiation	Disable packet-length negotiation facility
window-negotiation	Disable window-negotiation facility
user-group	Disable user-group facility
packet-length-negotiation	packet-length negotiation facility
interface	interface to match
priority	priority of this entry
reverse-charge	reverse charge facility option
user	serveral user facilities
bilateral-group	bilateral group type
normal-group	normal group type
outgoing-group	outgoing group type
id	user id
data	user data
window-negotiation	window-negotiation facility
XOT config>	

Each option has the following meaning:

- <id>                      Number of the facility entry (item).
- called                    Window size and packet length called facilities.
  - *window*                      Window size (1-128) default value 7.
  - *packet-length*              Packet length (1-4096) default value 256.
- caller                    Window size and packet length caller facilities.
  - *window*                      Window size (1-128) default value 7.
  - *packet-length*              Packet length (1-4096) default value 256.
- na-value                 NA value (digits or X)
- new-na-value            New NA value (digits, X or S). **S** suppresses the digit figuring in this position, **X** does not change it.
- no
  - *reverse-charge*              Disables the reverse charge facility option.
  - *packet-length-negotiation*    Disables the packet length negotiation facility option.
  - *window-negotiation*          Disables the window size negotiation facility option.
  - *user-group*                    Disables the user group facility option.
- packet-length-negotiation*    Enables the packet length negotiation facility option.

<i>interface</i>	Assigns an interface to which the outgoing calls facility is applied. In cases where this is not configured, the facility is applied to all the device's outgoing calls.
<i>priority</i>	Permits you to configure the priority for this entry. (0 a 9)
<i>reverse-charge</i>	Enables the reverse charge facility option.
<i>user</i>	Permits you to configure various user facilities.
<i>bilateral-group</i>	Configures the bilateral group type user.
<num>	Group number. (4 Hexadecimal digits from 0 to F).
<i>normal-group</i>	Configures normal group type user.
<num>	Group number. (2 Hexadecimal digits from 0 to F).
<i>outgoing-group</i>	Configures the closed user group type user with outgoing access.
<num>	Group number. (2 Hexadecimal digits from 0 to F).
<i>id</i>	User identifier (ASCII characters)
<i>data</i>	User data. (Characters in hexadecimal without 0x in front).
<i>window-negotiation</i>	Enables the window size negotiation facility option.

**Example :**

```
XOT Config>FACILITY 1 CALLED WINDOW 4 CALLED PACKET-LENGTH 128 NA-VALUE 232X2X3 RE
VERSE-CHARGE
XOT Config> FACILITY 1 CALLER WINDOW 4 CALLER PACKET-LENGTH 128
XOT Config>
```

## 1.6. LIST

Lists the different parameters.

**Syntax:**

```
XOT Config>LIST ?
ADDRESS
ALL
FACILITY
PORT
ROUTING
XOT Config>
```

a) LIST ADDRESS

Lists the address table.

**Example :**

```
XOT Config>LIST ADDRESS
X25 Address          IP Address          Altern. IP Addr.    Call Timeout.
      123456          1.1.1.1             1.1.1.2             30
XOT Config>
```

b) LIST ALL

Lists all the XOT configuration.

**Example :**

```

Config>LIST ALL
Port information: xot
Layer 3 Window: 2
Ext pkt mode: Disabled
Packet size: 128
Caller Number:
NA calling process: Outgoing calls
PVC low: 0
PVC high: 0
SVC low: 100
SVC high: 100
Channel Direction: DEC

  X25 Address          IP Address          Altern. IP Addr.  Call Timeout.
      123456                1.1.1.1            1.1.1.2             30

Interface      Con  Type of interface      CSR   CSR2  int
ethernet0/0    LAN1 Fast Ethernet interface fa200e00
serial0/0      WAN1 Frame Relay          fa200a00 fa203c00 5e
serial0/1      WAN2 X25                    fa200a20 fa203d00 5d
serial0/2      WAN3 X25                    fa200a60 fa203f00 5b
bri0/0         ISDN1 ISDN Basic Rate Int fa200a40 fa203e00 5c
x25-node       --- Router->Node          0 0
xot            --- XOT                    0 0
ip-router      --- Node->Router          0 0

Entry      Port      priority  routing      NA      UD
  1         serial0/1  0         N            XXXXXXXXXXXXXXXX

X.25 global data:
Max. datagram length: 1500
Backup recover attempt time: 0
Max dynamically added addresses: 10
Check input call: Enabled

Packet facilities:
num P  Port  NA          NNA          Wcd Wcr Lcd  Lcr  RC CUG  NUI/UD
1  0  serial0/1  XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX 7  7  256  256  N B/0434 rest/3
XOT Config>

```

**c) LIST FACILITY**

Lists the facilities table.

**Example :**

```

XOT Config>LIST FACILITY
Packet facilities:
num P  Port  NA          NNA          Wcd Wcr Lcd  Lcr  RC CUG  NUI/UD
1  0  serial0/1  XXXXXXXXXXXXXXXX XXXXXXXXXXXXXXXX 7  7  256  256  N B/0434 rest/3
XOT Config>

```

**d) LIST PORT**

Lists the XOT port parameters.

**Example :**

```

XOT Config>LIST PORT
Port information: xot
Layer 3 Window: 2
Ext pkt mode: Disabled
Packet size: 128
Caller Number:
NA calling process: Outgoing calls
PVC low: 0
PVC high: 0
SVC low: 100

```

```
SVC high: 100
Channel Direction: DEC
XOT Config>
```

### e) LIST ROUTING

Lists the routing table.

**Example :**

```
XOT Config>LIST ROUTING

Interface      Con      Type of interface      CSR      CSR2      int
ethernet0/0    LAN1     Fast Ethernet interface fa200e00          27
serial0/0      WAN1     Frame Relay             fa200a00 fa203c00  5e
serial0/1      WAN2     X25                     fa200a20 fa203d00  5d
serial0/2      WAN3     X25                     fa200a60 fa203f00  5b
bri0/0         ISDN1    ISDN Basic Rate Int    fa200a40 fa203e00  5c
x25-node       ---     Router->Node           0          0
xot            ---     XOT                     0          0
ip-router      ---     Node->Router           0          0

Entry      Port      priority      routing      NA      UD
1          serial0/1  0             N            XXXXXXXXXXXXXXXXXXXX
XOT Config>
```

## 1.7. NO

Permits you to delete a parameter or an element from a table.

**Syntax:**

```
XOT Config>NO ?
ADDRESS
FACILITY
NA-CALLING
ROUTING
XOT Config>
```

### a) NO ADDRESS

Permits you to delete an element from the address table.

**Example :**

```
XOT Config>NO ADDRESS
Value of NA? 1321231
XOT Config>
```

### b) NO FACILITY

Permits you to delete an element from a facility table.

**Example :**

```
XOT Config>NO FACILITY
facility id[1]? 1
XOT Config>
```

### c) NO NA-CALLING

Deletes the NA calling assigned to the XOT port.

**Example :**

```
XOT Config>NO NA-CALLING
Deleted NA-CALLING port xot
XOT Config>
```

#### d) NO ROUTING

Deletes a routing from the table.

##### Example:

```
XOT Config>NO ROUTING
route id[1]? 2
XOT Config>
```

### 1.8. RESTORE

Restores the default values.

##### Syntax:

```
XOT Config>RESTORE ?
ALL
PORT
XOT Config>
```

#### a) RESTORE ALL

Restores default values for all ports.

##### Example:

```
XOT Config>RESTORE ALL
Restored default values for all ports
XOT Config>
```

#### b) RESTORE PORT

Restores default values for the XOT port.

##### Example:

```
XOT Config>RESTORE PORT
Restored default values port: xot
XOT Config>
```

### 1.9. ROUTING

Permits you to associate the X.25 addresses with the physical ports. In order to eliminate a route, introduce the command **NO** in front of **ROUTING**. For further information, please see the section describing the **NO** command.

##### Syntax:

```
XOT config>ROUTING <id>
na-value      na value to match this entry
no
  re-route    disable re-route
port          port to route this na
protocol      protocol
priority      priority of this route
re-route      enable re-route
  exclusive   enable re-route excluding the incoming call port
  all         enable re-route for all ports
XOT config>
```

Each option has the following meaning:

<id>                    ROUTING entry number (item).

<i>na-value</i>	NA value to match to activate this route. (digets or X).
<i>port</i>	Port to route this NA. (serialx/x or ip-router).
<i>protocol</i>	Protocol identifier. You must introduce this value in hexadecimal.
<i>priority</i>	Priority for this route. The highest priority routing corresponds to the lowest number. (0-9)
<i>reroute</i>	Enables rerouting
<i>exclusive</i>	Enables rerouting, excluding the incoming call port.
<i>all</i>	Enables rerouting for all the ports.
<i>no re-route</i>	Disables rerouting.

(\*) The rerouting option permits you to carry out rerouting if the highest priority routing or route is unavailable or all its logical channels are busy. The possible values are:

Y: Yes carry out rerouting.

N: No do not carry out rerouting.

E: Exclusive rerouting: This option prevents an X.25 call from being routed towards the same port it came in by. I.e. if the highest priority routing routes the call towards a SVC of the same port the call entered through, then a search is carried out for other routings to other ports.

(\*\*) The Protocol identifier field permits routing to be carried out depending on the first octet in the user data field, which identifies the protocol. If this is not programmed, this field is ignored.

**Example :**

You configure:

<i>&lt;id&gt;</i>	3
<i>na-value</i>	32323XXXX
<i>port</i>	serial0/1
<i>priority</i>	1
<i>re-route</i>	Enable normal rerouting.

```
XOT config>ROUTING 3 PO serial0/1 NA 32323XXXX PRI 1 RE AL
```

**NOTE:** *The first time you introduce this command, you must enter as a minimum the <id>, port and na-value in the given order. Subsequently in order to change any parameter, you will only have to introduce the <id> and the parameters you wish to modify.*

## 1.10. SET

Assigns values to parameters.

**Syntax:**

```
XOT Config>SET ?
CHANNEL-DIRECTION
NA-CALLING
```

```
PACKET-SIZE
PACKET-WINDOW
PROCESS-NA-CALLING
SVC
XOT Config>
```

a) SET CHANNEL-DIRECTION

Permits you to define if the outgoing calls SVCs are to be assigned in descending or ascending order.

**Syntax:**

```
Config>SET CHANNEL-DIRECTION ?
DECREASING
INCREASING
XOT Config>
```

· SET CHANNEL-DIRECTION DECREASING

Assigns the channels in decreasing order beginning with the highest.

**Example:**

```
XOT Config>SET CHANNEL-DIRECTION DECREASING
XOT Config>
```

· SET CHANNEL-DIRECTION INCREASING

Assigns the channels in increasing order beginning with the lowest.

**Example:**

```
XOT Config>SET CHANNEL-DIRECTION INCREASING
XOT Config>
```

b) SET NA-CALLING

Permits you to configure the NA calling which is sent in the call request packets.

**Example:**

```
XOT Config>SET NA-CALLING
NA calling?123456
XOT Config>
```

c) SET PACKET-SIZE

Permits you to configure the packet size.

**Example:**

```
XOT Config>SET PACKET-SIZE
Packet size[1-4096][128]? 256
XOT Config>
```

d) SET PACKET-WINDOW

Permits you to configure the window size.

**Example:**

```
XOT Config>SET PACKET-WINDOW
Packet window(1-128)[2]? 7
XOT Config>
```

e) SET PROCESS-NA-CALLING

This option allows you to add or suppress the NA of the calling packets processed by the **Teldat Router**. The values that can be given are:

A: Automatic. Automatic according to the interface. If it is DCE the NA is added to the calls coming in through the port. If the interface is DTE, the NA is added to the outgoing calls.

S: Suppress. Suppresses the NA in all the calls passing through the port.

O: Outgoing calls. Adds the NA to the outgoing calls.

I: Incoming calls. Adds the NA to the incoming calls.

T: In all calls. Adds the NA to all calls.

**Example :**

```
XOT Config>SET PROCESS-NA-CALLING
Calling NA process (T,S,I,O,A)O: S
XOT Config>
```

f) SET SVC

Configures the logical channels.

**Syntax:**

```
XOT Config>SET SVC ?
LOW
HIGH
XOT Config>
```

· *SET SVC LOW*

Configures the lowest logical channel.

**Example :**

```
XOT Config>SET SVC LOW
SVC low[0-4096][100]?1
XOT Config>
```

· *SET SVC HIGH*

Configures the highest logical channel.

**Example :**

```
XOT Config>SET SVC HIGH
SVC high[0-4096][100]?10
XOT Config>
```

## 1.11. EXIT

Use the **EXIT** command to return to the previous prompt.

**Syntax:**

```
XOT Config>EXIT
```

**Example :**

```
XOT Config>EXIT
Config>
```



# Chapter 3

## Monitoring



# 1. Monitoring Commands

---

The XOT Protocol monitoring is accessed through the main menu in the following way:

1. At the (\*) prompt, enter PROCESS 3 (or P 3).
2. At the monitoring (+) prompt, enter NODE XOT.
3. At the XOT protocol monitoring (XOT>) prompt, use the monitoring commands described in this chapter to monitor the Teldat router parameters.

In this chapter the XOT monitoring commands are explained in detail.

Command	Function
? (HELP)	Lists the available commands or their options.
LIST	Lists the TCP servers state.
EXIT	Returns to previous prompt.

## 1.1. ? (HELP)

Displays a list of available commands or their options.

**Syntax:**

```
XOT>?
```

**Example:**

```
XOT>?  
LIST  
EXIT  
XOT>
```

## 1.2. LIST

**Syntax:**

```
XOT>LIST ?  
STATE  
XOT>
```

### a) LIST STATE

Lists the TCP servers state.

**Example:**

```
XOT>LIST STATE  
  
Total Servers:      0  
Servers listening:  0  
Servers opened:    0  
Servers clients:   0  
XOT>
```

## 1.3. EXIT

Use the **EXIT** command to return to the previous prompt.

**Syntax:**

```
XOT>EXIT
```

**Example :**

```
XOT>EXIT  
+
```

# Chapter 4

## XOT Interfaces



# 1. Creating XOT interfaces

---

Firstly you need to create the XOT interface.

This is achieved through the configuration menu using the **ADD DEVICE XOT** command. This creates the interface and assigns an interface name.

```
*P 4
User configuration
Config>ADD DEVICE XOT
Added XOT interface xot
Config>
```

A list of the interfaces configured in the **Teldat Router** can be seen by entering the **LIST DEVICES** command after the user configuration prompt *Config>*.

```
*P 4
User configuration
Config>LIST DEVICES
Interface      Con   Type of interface          CSR   CSR2  int
ethernet0/0   LAN1  Fast Ethernet interface    fa200e00      27
serial0/0     WAN1  Frame Relay                fa200a00 fa203c00  5e
serial0/1     WAN2  X25                        fa200a20 fa203d00  5d
serial0/2     WAN3  X25                        fa200a60 fa203f00  5b
bri0/0        ISDN1  ISDN Basic Rate Int       fa200a40 fa203e00  5c
x25-node      ---   Router->Node              0           0
xot           ---   XOT                        0           0
Config>
```

When you create an XOT interface, the routing is carried out towards it by using the node routing commands. It is only necessary to create one XOT interface as the X.25 calls are routed with an IP address.

## 2. Configuring XOT Interfaces

---

Before configuring the XOT protocol, it is advisable to have the corresponding part for the IP protocol configured so the addresses are assigned to the interfaces.

In order to achieve the XOT protocol configuration, the following operation must be carried out:

From the system console, type P 4 to access the configuration process.

```
*
*p 4
Config>
```

- Accessing the XOT prompt

From the configuration prompt, enter the command **NODE XOT** to access the XOT port configuration.

### Syntax:

```
Config>NODE XOT
```

### Example :

```
Config>NODE XOT
XOT Config>
```

- To display the present values of the port you wish to use on screen

Enter the command **LIST PORT** at the XOT prompt *XOT Config>*.

### Example :

```
XOT Config>LIST PORT
Port information: xot
Packet window: 2
Ext pkt mode: Disabled
Packet size: 128
Caller Number: 101010
NA caller process: Automatic
PVC low: 0
PVC high: 0
SVC low: 100
SVC high: 100
Channel Direction: DEC
XOT Config>
```

### 3. Configuring the X.25 parameters

---

The meaning of the commands and the parameters which modify them are as follows:

#### Packet window

Specifies the maximum number of X.25 packets awaiting acknowledgment. This window can have values between 1 and 128. Default value is 2.

#### Example :

```
XOT Config>SET PACKET-WINDOW
Packet window(1-128)[ current value]?window_size
XOT Config>
```

#### Extended Packet Mode

Specifies the PS field module for the X.25 network level. This is the module used to consecutively number the sent X.25 packets and can have a value between 8 and 128 corresponding to the Disable and Enable values in this parameter. The default value is 8 (Disabled).

#### Example :

```
XOT Config>ENABLE EXTENDED-PACKET-MODE
XOT Config>
```

Or:

```
XOT Config>DISABLE EXTENDED-PACKET-MODE
XOT Config>
```

#### Packet size

Specifies the maximum length of an X.25 packet. The length is limited to 4,096 octets. The default value is set to 128 octets.

#### Example :

```
XOT Config>SET PACKET-SIZE
Packet size[1-4096][current value]?packet_size
XOT Config>
```

#### NA Calling

The NA (Network Address) is the X.25 calling address for the request call packets exiting through the port. This is independent from the NA which they were received with in the **Teldat Router**. This is not programmed by default.

#### Example :

```
XOT Config>SET NA-CALLING
NA calling?na_calling
XOT Config>
```

This number can consist of up to 15 ASCII characters.

In order to delete, use the **DELETE NA CALLING** command.

#### Process NA calling

This option allows you to add or suppress the NA of the call packets processed by the **Teldat Router**. The values that can be given are:

A: Automatic. Automatic according to the interface. If it is DCE the NA is added to the calls coming in through the port. If the interface is DTE, the NA is added to the outgoing calls.

S: Suppress. Suppresses the NA in all the calls passing through the port.

O: Outgoing calls. Adds the NA to the outgoing calls.

I: Incoming calls. Adds the NA to the incoming calls.

T: In all calls. Adds the NA to all calls.

**Example :**

```
XOT Config>SET PROCESS-NA-CALLING
Calling NA process [T,S,I,O,A] I: S
XOT Config>
```

**SVC low**

Indicates the lowest SVC number that can be used in X.25 communications. The range of permitted values is from 0 to 4.096. The default value is 100.

**Example :**

```
XOT Config>SET SVC LOW
SVC low [0-4096] [current value]?SVC_low
XOT Config>
```

**SVC high**

Indicates the highest SVC number that can be used in X.25 communications. The range of permitted values is from 0 to 4.096. The default value is 100.

**Example :**

```
XOT Config>SET SVC HIGH
SVC high [0-4096] [current value]?SVC_high
XOT Config>
```

The number of logical channels are only significant at an internal level and do not necessarily have anything to do with the X.25 ports. The important point is the total number of the logical channels which are configured as this determines the maximum number of connections.

**Channel direction**

Specifies if the logical channel numbers are used in ascending or descending order. The possible values are *INCREASING* and *DECREASING*. The default value is decreasing.

**Example :**

```
XOT Config>SET CHANNEL-DIRECTION INCREASING
XOT Config>
```

Or:

```
XOT Config>SET CHANNEL-DIRECTION DECREASING
XOT Config>
```

### 3.1. Assigning Addresses

The following commands are used to associate X.25 addresses to IP destination addresses.

**Add address**

**Example :**

```
XOT Config>ADDRESS 21324242 IP 192.22.24.56 AL 172.43.55.23 TI 120
XOT Config>
```



## List address

### Example :

```
XOT Config>LIST ADDRESS
  X25 Address      IP Address      Altern. IP Addr.  Call Timeout.
      21324242      192.22.24.56      172.43.55.23      30
XOT Config>
```

## Delete address

### Example :

```
XOT Config>NO ADDRESS
Value of NA? 21324242
XOT Config>
```

In the examples given, the calls with NA 21324242 are sent to the router with the following IP address 192.22.24.56

It is unnecessary to add the addresses to the incoming calls.

If the alternative IP address is left as 0.0.0.0, the alternative IP connection feature is not used.

## 3.2. Liberation causes and diagnostics

Under the following circumstances, a call directed to an XOT interface is released.

Cause (hex)	Diagnostic (dec)	Motive
0D	120	A specific NA/addr association has not been configured.
09	120	A specific IP address cannot be reached.
11	119	Timer period has finalized in the TCP connection. The remote stops answering TCP packets.
09	119	The remote has closed the TCP connection.